


## 4G ADJUSTMENT INSTRUCTIONS

### To adjust platform height:

Lift front edge of keyboard platform and position at desired height. The platform will automatically lock into place when released.



### To adjust platform tilt:

Turn dial (a) to desired degree of tilt.

*(Note: It may be easier to lift front of platform while turning.)*

